

Technical Data Sheet

Inspection and Tightening of the Mansfield 8010 Threaded Rods

Date: 1/7/2003

Page: 1 of 1

TOOLS REQUIRED:

9/16" Deep Socket

We have discovered that some of the first Mansfield's have feet that have become loose when the dealer originally inspects the stove. This problem can be easily fixed using a 9/16" deep socket to tighten the nut against the top of the foot and bottom cast.

Here is how to tighten the nut on each corner tie rod if needed:

1) PLEASE BE SURE TO KEEP THE STOVE BOLTED TO THE PALLET BEFORE SNUGGING THE NUTS.

2) Use a 9/16" deep socket to tighten each corner tie rod connecting the foot to the bottom cast. These nuts are located at the inside top of each foot, below the bottom cast.