

Technical Data Sheet

Champlain 8301 & Stowe 8321 Decorative Plug Installation *Kit #90-99300*

Publish Date: 04/25/2006

MATERIALS REQUIRED:

(2) 4700-0608 Black Oxide Decorative Plugs

TOOLS REQUIRED:

None

BEFORE YOU BEGIN: Follow the instructions in the manual to remove the front panel and install the logs. The screws removed from the top of the front panel are for shipping purposes only and are not reinstalled. The holes once occupied by these screws is where you install these plugs.

PROCEDURE:

- 1) Use the enclosed plugs as finishing touches after the logs are installed and the front panel is back on the face of the stove. Simply push the plugs into the holes on the top of the front panel (as shown in photo #1).



Photo #1
Insert the plug, prongs first, into the top holes on the front panel



Photo #2
The plugs installed in the front panel.

- 2) If the plus are too loose, remove them and spread the prongs apart slightly, then push them back into the holes.