

Technical Data Sheet

Outside Air Kit Installation Instructions for the Bari Wood (8170) ***Kit #91-53700***

Publish Date: 10/29/2007

KIT CONTENTS:

- 1-Outside air box
- 2- Mounting screws (DIN 7991 M6x40)

TOOLS REQUIRED:

4mm or 5/32" Hex wrench

If you are planning on using the Stove Lock-Down Kit (91-99400) (Mandatory in all mobile home installations) you must install that kit before proceeding with this installation.

PROCEDURE:

1. Unpack and locate the Outside Air Box.
2. Place this box behind the stove near the floor. (see *Figure #1*)



Figure 1

3. Align the two holes in the box over the two holes in the back of the stove.
4. Using the 2 mounting screws, attach the box to the stove with the hex wrench.
5. If your air inlet comes up through the floor, simply reverse the box and direct the opening down.