

# **Technical Data Sheet**

## **Lock-down Kit Installation Instructions for the Tula (8191)**

Kit #91-99910

#### **INCLUDED IN KIT:**

### **TOOLS REQUIRED:**

- 1-Lock down plate
- 1-Flat Washer
- 1- 10mm Length Black Oxide Screw

- 2-Screws to mount plate to floor
- 1-Screwdriver/Drill
- 1- 4mm Hex wrench



Figure 1 – Lockdown plate, with hardware

This kit is mandatory when installing the Tula 1 in a mobile home.

BEFORE YOU BEGIN: Always work on a cool stove.

#### PROCEDURE:

- 1. Unpack kit contents to be sure you have everything.
- 2. Depending upon your floor material (stone, brick, wood, tile, etc.) choose a screw that is strong enough to hold the Tula in place. Large sheet rock screws will work for wood flooring.



Revision: 04/17/17 Page: 2 of 2

- 3. Carefully tip the Tula forward, just enough to slip the bracket under the stove centering it with the hole on the bottom, in the back. Be sure that the side with 2 holes in on the floor, and the single hole in the bracket lines up with the single hole in the stove body.
- 4. Thread the included screw with washer through the stove, and into the hole in the bracket.
- 5. With stove in desired location, screw 2 screws through bracket and into your floor, securing the stove to your floor.