

# **Technical Data Sheet**

## **Tula 8191 Front Stone Panel Installation Instructions**

Assembly 9190-41

### **INCLUDED IN KIT:**

### TOOLS REQUIRED:

(1) 1141-900 Front Soapstone Panel

#### 3mm Hex Key

**Before You Begin**: Work on a cool stove. Locate the hex key and retaining screw shipped with the stove. Have them ready for use in installing the stone panel.

1) Locate the two screw/posts on the front bottom flange of the stove (see photo number 1).



Photo # 1: Bottom Stone Mounting Posts

2) Locate the two holes on the bottom of the stone panel. Line these holes up with the mounting post in Photo #1 and carefully set the stone onto the stove so that



the posts are inserted in to the holes on the bottom of the stone and the stone sets down flush to the flange.

3) While holding the stone in this position, flush to the front of the stove, use a 3mm hex key to turn in the set screw (provided with the stove) that will hold the stone in place on the top (see photo number two). Turn it in far enough to apply pressure to the stone, but not so far as to gouge the stone.



Photo #2: Turning in the setscrew on the top of the stone