



TECHNICAL DATA SHEET
Kit #93-57306

INSTALLATION OF H-III DELUXE REAR HEAT SHIELD

TOOLS REQUIRED:

7/16" Wrench

KIT #93-57306 INCLUDES:

- 1 - Deluxe Shield
- 2 - 1/4"-20 x 1 1/4" Hex Head Bolts
- 2 - Spacers

PROCEDURE:

1. Remove the two bolts in the back of the secondary combustion chamber.
2. Position the heat shield on the back of the stove with the mounting bracket down. Place the spacers between the stove back and the shield to allow a space between the stove and the shield. Insert the bolts provided through the shield, the spacers, and into the threaded holes in the back of the stove to attach the shield. Tighten the bolts with the 7/16" wrench.

NOTE: Some models of the HearthStone III do not have the two screws on the back of the secondary combustion chamber. You must drill and tap these holes yourself before you can attach the shield.

Mark the center of the secondary combustion chamber and drill two 13/64" holes 1/2" and 3" down from the top of the chamber. Tap these holes using a 1/4"-20 tap. Attach the shield as above.

NOTE: Follow the clearances outlined in the Owner's Manual.