

Technical Data Sheet

Manchester 8360/8361 Baffle Replacement Instructions

Assembly 93-76600

INCLUDED IN KIT:

- (1) 3120-360 Ceramic Baffle
- (1) 5021-066 Baffle Bracket
- (2) 4300-0120 2" cotter pin

TOOLS REQUIRED:

- Work Gloves
- Pliers
- Safety Glasses

BEFORE YOU BEGIN: *Always work on a cool stove!*

PROCEDURE:

- 1) Note the placement of the cotter pins that hold the baffle to the middle secondary air pipe (this will be important when installing the new baffle). Using the pliers, straighten the pins and remove them.
- 2) The original baffle is now loose. Remove the damaged baffle from the firebox. Note: there may be fly ash and other debris on top of the baffle, use care when removing the damaged piece(s). Lift the back end of the baffle up so that the front edge of the baffle clears the front air pipe. It can now be pulled down between the first and second air pipes. Pull it completely out of the stove. Discard the used baffle.
- 3) Place the new baffle in the firebox with the stainless steel bracket on top of the baffle. Position the indented edge of the baffle down, and toward the front of the firebox. This will rest on the baffle support on the front air pipe.
- 4) Slide the back end of the new baffle up between the first and second air pipes, keeping the bracket on top of the baffle. Position it so that the front edge of the baffle sits flush against the front support.
- 5) Work the cotter pins down through the bracket, baffle, and middle air pipe – in the same location where they were removed from the original baffle. Once they drop through all three pieces, twist the ends with pliers to keep them in place.

