



## Technical Data Sheet

### Installation of the Morgan/Clydesdale Surround Extension Kit

*Morgan Kit# 94-5970010, Clydesdale Kit #94-5990010*

**Date:** 7/1/2004

**Page:** 1 of 2

#### KIT CONTENTS:

- 1 – Left panel
- 1 – Right panel
- 1 – Center panel
- 4 – Tapped corner connectors (with holes)
- 4 – Back plates connectors (without holes)
- 8 – Set screws

#### TOOLS REQUIRED:

Screwdriver, flat blade

**Note: Only install the surround extension kit on a cold insert. Make sure the fire in the unit has been out for at least 5 hours.**

#### **PROCEDURE:**

1. Carefully unpack the surround from its shipping container.
2. Place the surround panels face down on a soft surface. Place the mitered ends of the *left* and *right panels* flush to the mitered ends of the *center panel*
3. Slide an untapped *back plate connector* and a *tapped corner connector* into the two slots on both *side panels*. (Make sure the *tapped corner connectors* are on the top, facing you.)
4. Place the *center panel* in place by sliding the *corner connectors* in the slots on the mitered ends. Push the corners together firmly and evenly, while tightened the set screws. Take care to not over tighten the screws.
5. Gently pull the Morgan/Clydesdale away from the fireplace about 2 inches.
6. Next, stand the assembled surround extension up on the *left* and *right panels*. Lift, by the *center panel*, and slide down behind the Morgan/Clydesdale existing surround.
7. Center the surround extension around the existing unit to a position of your liking.
8. Carefully push the insert back into place, gently sandwiching the surround extension in place.

317 Stafford Ave. Morrisville, VT 05661

(802) 888-5232

[Http://www.hearthstonestoves.com](http://www.hearthstonestoves.com)

(802) 888-7249