

TDS9473910 Revision: 8/9/2012

# **Technical Data Sheet**

# Installation of the Manchester 8360 Side Door Latch Kit Kit 94-73910

### **INCLUDED IN KIT:**

Quantity	Part Name	Part Number
1	5/16 - 18 x 3/8" set screw, allen	4500-2976
3	Door latch spacers (low profile washers)	4700-0790
1	Flat washer (.406" ID x 1" OD)	5021-032
1	Latch spring	5240-138
2	Latch	5491-048

#### **TOOLS REQUIRED:**

5/16" allen wrench High temperature grease

BEFORE YOU BEGIN: Install on a cool stove only!!

#### **INSTALLATION PROCEDURE:**

- 1. Open side door slightly.
- 2. Remove the set screw on the outside of the cast iron crank assembly with the 5/32" allen wrench (see Photo 1).
- 3. Turn the cast crank counterclockwise until it separates from the threaded latch shaft. Retain the cast iron crank for the reassembly.
- 4. Push the latch shaft through the door and discard the original latch, washers, and coil spring.
- 5. Place two of the adjustment washers onto the new latch shaft (an extra washer is included in the kit).
- 6. Apply a small amount of high temp grease to the smooth area of the shaft.
- 7. Push the latch through the hole in the door and slide the 1" OD washer over the outside portion now sticking through the door.
- 8. Place the coil spring onto the latch on top of the 1" OD washer,
- 9. Thread the cast iron crank back onto the latch shaft until it is about 1/8" from the surface of the door. Line the hole in the crank up over the groove in the shaft and lock the pieces together by turning in the setscrew. The tab on the end of the setscrew will insert into the notched groove in the edge of the latch shaft. Tighten the assembly with the allen wrench.


**Note**: If the door latch does not close firmly or is too difficult to close, the latch system is adjustable. To adjust, loosen the set screw and turn the cast crank in or out to make the initial adjustment. If more adjustment is

needed, separate the crank and latch and add a shim washer to loosen the assembly or subtract a washer to tighten it. Assemble the pieces as described in step 6 (see Figure 1).



# **MANCHESTER SIDE DOOR LATCH INSTALLATION**

Photo 1



## **MANCHESTER SIDE DOOR LATCH KIT**

Figure 1