



Technical Data Sheet

Installation of the Homestead Freestanding Conversion Kit

Assembly #95-5070010

Publish Date: 12/26/2001

ASSEMBLY CONTENTS:

- (1) #5930-2005 - Bottom Heat Shield
- (2) #5930-2006 - Bottom Heat Shield Brackets
- (2) #4500-3435 – 8-32 x 3/8" Screws
- (4) #25XX-705 – 6" Feet (XX = Foot Color)*
- (4) #4500-3200 – 5/16" x 1" Bolts

TOOLS REQUIRED:

- 1/2" Wrench
- Phillips Screwdriver

BEFORE YOU BEGIN:

Each side of the stove must be propped up in order to replace the standard hearth mount feet (4") with the freestanding (6") feet. Since the weight of the stove is approximately 360 lbs, use 2, or more persons to make this conversion.

PROCEDURE:

1. Lift one side of the stove and place a large, sturdy block of wood underneath it to hold it just over six inches off the floor. Using a 1/2" wrench, remove the bolts holding the original feet to that side of the stove. Place the taller feet onto the stove and secure them with the 5/16" x 1" bolts provided in this kit - while reusing the lock washers from the original feet. Repeat on the other side.
2. Clip the heat shield brackets into the slots on the bottom heat shield with the longer portion (the tab with the perforation) on the bracket extending up.
3. Slide the heat shield underneath the stove with the brackets up. Line the brackets up with the pre-existing holes on the left and right side of the ash dump. Affix the heat shield to the ash dump using the 2 screws provided with the kit.

 Order kits by the color of the cast iron finish on the stove as follows:

- 95-5070010** – Black Matte Paint (includes #2510-705 matte feet)
- 95-5070020** – Brown Enamel (includes #2520-705 brown feet)
- 95-5070050** – Black Enamel (includes #2550-705 black feet)
- 95-5070059** – Blue/Black Enamel (includes #2559-705 B/B Feet)
- 95-5070061** – Seafoam Enamel (includes #2561-705 Seafoam Feet)

Discontinued colors - check for availability:

- 95-5070030** – Almond Enamel (includes #2530-705 almond feet)
- 95-5070066** – Navy Enamel (includes #2566-705 navy feet)
- 95-5070080** – Green Enamel (includes #2580-705 green feet)