

# Technical Data Sheet

## Installation of the Starlet Glass and Gasket Kit *Assemblies 95-58501 (Gasket) & 94-58405 (Glass)*

**Date:** 1/8/2003

**Page:** 1 of 2

**Note:** Glass kit number 94-58405 is also used on the Harvest catalytic wood stove, the EPA exempt American Heritage wood stove, and all Sterling Gas Models.

### **Gasket Kit #95-58501:**

5 - Feet 1/4" Rope Gasket  
5 - Feet 3/4" Flat Tape Gasket  
1 - Gasket Glue

### **Glass Kit #94-58405:**

5 - Feet 3/4" Flat Tape Gasket  
1 - Ceramic Glass

### **Tools Required:**

Scissors  
Steel Wool or Wire Brush  
Phillips Screwdriver  
Penetrating Oil

**Before You Begin:** Work on a cool stove.

### **Procedure to Replace the Door Gasket:**

1. Remove the door by lifting it straight up off the hinges with the hinge pins remaining in the door. Place it face down. (Use soft surface for enameled doors.)
2. Pull out used gasket from channel and discard. Clean gasket channel using steel wool or wire brush; remove any residue. Wipe clean with damp rag or cloth.
3. Using the gasket adhesive, apply a thin bead of the adhesive to the gasket channel.
4. When the adhesive becomes "tacky", apply the new gasket by pushing it into the channel.
  - To get a proper seal, do not stretch or bunch the gasket.
  - Do not start in a corner; it will be more easily pulled out.
  - Try to use as much of the gasket as you can.

-Cut off any excess with the scissors.

5. The doors should be returned to the stove a.s.a.p. and shut tightly to assure a positive seal.

### **Procedure to Replace the Glass & Glass Gasket:**

Follow this procedure to replace the glass on the Harvest and American Heritage wood stoves and all models of the Sterling gas stoves.

1. Open the front door (on Sterling gas models, remove the phillips screw with a phillips screwdriver). Remove the door by lifting it straight up off the hinges with the hinge pins remaining in the door. Place it face down. (Use a soft surface for enameled doors.)

**Hint:** With the door in this position apply penetrating oil to each of the retaining screws in the glass frame before attempting to remove the screws.

3. With the phillips screw driver, remove the window frame screws to separate the window frame from the door.
4. Carefully lift the glass from the door.
5. Peel the paper backing from the backside of the flat gasket, a small amount at a time. Wrap the tape around the outside edge of the glass, overlapping both the front and back of the glass.
6. Place the gasketed glass back into the door and screw the glass retention frame back onto the door to hold the glass in place.
7. Install and close the door. On Sterling gas models, secure the door by turning in the screw with a Phillips screwdriver.