

# Technical Data Sheet

## Installation of the Starlet Gasket Kit

*Assembly 95-58501*

### **INCLUDED IN KIT:**

(5 Feet) 3110-057 3/4" rope Gasket  
(5 Feet) 3160-080 3/4" Flat Tape Gasket  
(1) 99-090N 2oz Gasket Glue

### **TOOLS REQUIRED:**

Pair of Work Gloves  
Scissors  
Wire Brush or Steel Wool  
Penetrating oil  
Phillips Screwdriver

**BEFORE YOU BEGIN:** *Always work on a cool stove!*

### **PROCEDURE:**

- 1) Remove the door by lifting it straight up off the hinges, with the hinge pins remaining in the door. Place it face down. (Use a soft surface for enameled doors).
- 2) Pull out used gasket from the channel and discard. Clean the gasket channel using a wire brush or steel wool; remove any residue. Wipe clean with a damp rag or cloth.
- 3) With the door face down, apply penetrating oil to each of the screws in the glass frame. Allow the oil to soak for approx. 10-15 minutes.
- 4) With a Phillips screwdriver, remove the glass frame screws to separate the glass frame from the door.
- 5) Remove the old gasket from the glass, and clean glass by applying stove glass cleaner, or a wet rag and white ash. Never use anything abrasive to clean your glass.
- 6) Peel the paper backing from the backside of the flat gasket, a small amount at a time. Wrap the tape around the outside edge of the glass, overlapping both the front and back of the glass.
- 7) Place the gasketed glass back into the door and screw the glass retention frame back onto the door, to hold the glass in place.
- 8) Apply gasket glue to previously prepared gasket channel. When glue becomes tacky, apply new gasket into channel, starting in between door hinges. Take care not to stretch gasket. Trim any excess gasket, once you have gasketed the entire door.
- 9) Install the freshly gasket door back onto the stove.