

## Technical Data Sheet

### Installation of the Sterling 4" X 6-5/8" Rear Exit Starter For Sterling Direct-Vent Model #8531 *Assembly 95-60924HC*

**Date:** 1/2/2003

**Page:** 1 of 1

**KIT CONTENTS:**

- (16)#4500-3435 - Screws 8-32 X 3/8" Type F PH
- ( 1)#3160-101 - 5" X 6-1/2" Gasket Ring
- ( 1)#3160-102 - 8" X 9-1/2" Gasket Ring
- ( 1)#5701-0924HC - 4" X 6-5/8" Rear Exit Starter Kit

**TOOLS REQUIRED:**

Phillips Screwdriver

**BEFORE YOU BEGIN:** To properly complete this installation you will be required to install not less than 2 feet of vertical rise in the pipe.

**PROCEDURE:**

- 1) Remove the temporary shipping screws from the inner collar mounting holes.
- 2) Check venting charts in Owner=s Manual to determine if a restrictor plate is required. If so, follow the instructions provided with the restrictor plate. If not, continue to step 4.
- 3) Place the 5" X 6 1/2" gasket ring onto the base of the small inner (4") portion of the stove adaptor. Attach them both to the stove using 8 of the screws provided.

**HINT:**

Use Spray >N Glue or liquid gasket glue to help hold the gasket rings in place during assembly.

- 4) Place the 8" X 9-1/2" gasket ring onto the outer (6-5/8") portion of the stove adaptor. Attach them to the stove using the remaining 8 screws.

To complete the installation follow the instructions provided by Dura-Vent. Make sure all stove and termination clearances outlined in the Owner's Manual have been properly observed.