

Technical Data Sheet

DVI-Ht 8890 Brown Brick Panels and Ember Fillers Installation

Kit #98-83900

Publish Date: 4/4/2006

Tools Required:

Flat Head and Cross-tip Screwdrivers
½" wrench or socket and ratchet

<u>ITEM</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	3120-894	Left Filler	1
2	3120-895	Right Filler	1
3	3120-896	Side Brick Panel	2
4	3120-897	Rear Brick Panel	1
5	5890-045	Side Panel Retaining Clip	2

Procedure:

1. Remove the Façade by lifting up and leaning the top out toward the room.
2. Remove the Glass/Frame from the firebox. With a flat screwdriver pry the retaining clips up. There will be four separate clips. Be careful, when you lift the last one, as it will free the glass and frame from the unit. Place the glass and frame in a safe place.



3. Remove the old brick patterned Filler pieces and right hand log from the stove.
4. Remove the stainless steel baffle by removing the two bolts using a ½" wrench or socket.



5. Remove and discard the two Side Panel retaining Clips at the top center of both panels using a Philips screwdriver. Retain the screws for the new Clips.



6. Remove the old brick panels by first tilting the top of the sides in and then maneuvering them out of the firebox. The Rear Panel can then be removed.
7. Install the new Panels in the reverse order.
8. Install the new (deeper) Side Panel Clips and position them down to retain the panels.
9. Install the Baffle, new Filler pieces, and finally the right hand log.
10. Reassemble the Glass/Frame and Façade in the reverse order of step #1 and 2.

