



# Technical Data Sheet

## DVI-Ht 8890 Grand Threshold Install *Accessory Kit 98-8450010\**

**Publish Date: 8/2/2005**

**Tools Required:**

Cross-tip Screwdriver

Appliance Blanket, Tarp, or Similar Protective Surfacing

\*Part number for matte black finish. Assembly procedure is identical for all finishes.

<u>ITEM</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>QTY.</u>
1	2810-537	CENTER THRESHOLD SECTION	1
2	2810-535	LEFT THRESHOLD SECTION	1
3	2810-539	RIGHT THRESHOLD SECTION	1
4	5890-200	THRESHOLD BRACKET	2
5	4500-3436	#10-24x3/8" SCREW	8

**Hardware Included:**

<b>Qty</b>	<b>Description</b>
8	#10-24 x 3/8" Black Oxide Screws

**Procedure:**

1. Protect a work area on the floor with an appliance blanket, tarp, or other protective material. This will prevent damage to the floor and protect enameled pieces from chipping.
2. Arrange the cast pieces (top down) on your work surface, as shown in the diagram.
3. Align the steel brackets with the holes and install the included #10-24x3/8" screws.
4. Install the Threshold Assembly by raising the firebox enough to slide it under the firebox.
5. Lower the firebox onto the threshold and align.

