

Technical Data Sheet

Installation of the DVI Threshold

Date: July 18, 2005

Re: DVI *Fireplace Insert* (Model 8870, 8890)

Tools Required:

Phillips Screwdriver

Appliance Blanket, Tarp, or Similar Protective Surfacing

Before You Begin:

The venting, gas connection, and electrical connections should be made before proceeding with the following instructions. This procedure is used for either the small or large surrounds.

Identify the necessary components as follows (to help identify the pieces, see illustrations):

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	2810-970	CENTER THRESHOLD SECTION	1
2	2810-969	LEFT THRESHOLD SECTION	1
3	2810-971	RIGHT THRESHOLD SECTION	1
4	5890-200	THRESHOLD BRACKET	2
5	4500-3436	#10-24x3/8" SCREW	8

Note:

The cast iron numbers listed above are for black matte pieces. Substitute the following prefixes for enamel colors: Brown 2820/Almond 2830/Black 2850/Navy 2866/Green 2880. For the Façade Kit, substitute the following numbers for the xx in the kit number: 10 = Matte, 20 = Brown, 30 = Almond, 50 = Black, 66 = Navy, and 80 = Green.

Hardware Included:

Qty: Description:

8 #10-24 x 3/8" Black Oxide Screws

Procedure:

1. Protect a work area on the floor with an appliance blanket, tarp, or other protective material. This will prevent damage to the floor and protect enameled pieces from chipping.
2. Arrange the cast pieces (top down) on your work surface, as shown in the diagram.
3. Align the steel brackets with the holes and install the included #10-24x3/8" screws.

