

Technical Data Sheet

GMI90 8460 Replacement Baffle Kit Installation *Assembly 94-76600*

INCLUDED IN KIT:

- (1) Replacement Baffle

TOOLS REQUIRED:

- Vise Grips

Before You Begin: Work on a cool stove.

- (1) Starting with the front tube, remove the tubes (A) by rotating the tube clockwise to align the slot in the tube with the key in the tube retainer. Slide the tube to the right to disengage the tube, then lean the tube down into the firebox to remove. Be sure to keep it straight which tube is which for reinstall.
- (2) Remove the old baffle (B)
- (3) Install the new baffle
- (4) Replace the tubes in reverse order from how they were removed. Be sure to rotate the tubes enough that the key fully engages in the slot on the tube.
- (5) Perform the break in fire procedure as defined in the stove manual for the first few fires to properly cure the baffle.

