

Technical Data Sheet

Green Mountain 20 8620: Rear Heatshield Installation

Assembly 96-68200

INCLUDED IN KIT:

(1) 5920-010 Rear Heat Shield

TOOLS REQUIRED:

Phillips Screw Driver

Before You Begin: Only work on a cool stove.

1. Locate and loosen the two rear-most phillips screws securing the bottom shield to the stove.



2. Next, hook the top edge of the heat shield under the top rim of cast iron.
3. Finally, line up the two slots in the bottom flange of the heat shield with the screws loosened in Step 1. Slide the bottom flange between the screws and bottom heatshield and tighten the screws to secure the shield in place.

