

Addendum

Handle Attachment

Mansfield Model 8011 – Stoves manufactured after November 15, 1999

Heritage Model 8020 – Stoves manufactured after March 01, 2000

Handle Installation:

Handles on these units can be permanently attached. The ash door handles on both stoves as well as the front door handle on the Heritage are installed at the factory. The Mansfield front handle and Heritage side door handle can be installed as follows:

Locate the handle, bolt, and washers enclosed in the envelope with the owner's manual and warranty. Place the washers on the bolt and then push it through the handle so that the bolt threads extend through the bottom of the handle. Using a slotted screwdriver turn the bolt into the chrome latch on the Heritage side door or Mansfield front door until snug.

Handle Operation:

Front Door Mansfield/Heritage – when closed, the handle will be in the 8 o'clock position. To open the front door, rotate the latch clockwise to approximately the 10 o'clock position.

Ash Pan Door Mansfield/Heritage - when closed, the handle will be in the 6 o'clock position. To open the ash door, rotate the latch counterclockwise to approximately the 3 o'clock position.

Side Door Heritage – when closed, the handle will be in the 5 o'clock position. To open the side door, rotate the latch counterclockwise to approximately the 2 o'clock position.

This addendum will supercede information found in the Heritage owner's manual (#6400-40420). Please read your owner's manual thoroughly before operating your stove. We advise that you **keep this addendum with your owner's manual** for any future references.

S:/SERVICE/TECH/ADDENDUM HANDLES

