

Technical Data Sheet

Installation of the Tribute 8040 Viewing Screen

Assembly 90-69400

Publish Date: 5/26/2004

KIT CONTENTS:

(1) Spark Screen w/ Knob

TOOLS REQUIRED:

None

BEFORE YOU BEGIN: Install retainer to screen. Turn threaded rod into screen through the tab on the top inside of the screen. Turn nut and knob onto the threaded rod outside the screen and adjust to fit screen tight to door frame.

HINT: Burn the stove briskly before attempting to use the screen. This allows the draft to strengthen and decrease the possibility for smoke spillage.

PROCEDURE:

1. Start with the screen handle at the top and facing you.
2. Turn the knob counterclockwise until the tab on the back of the screen is in the 6 o'clock position.
3. Open the door on the stove.
4. Hold on to the screen handle, set the lower edge of the screen onto the lower edge of the front door frame. (Ensure you place the bottom prongs behind the lip of the lower door opening.)
5. Push the top of the screen toward the stove until the top of the screen makes contact with the top of the door opening.
6. Turn the screen handle clockwise so the tab on the back of the screen is in the 12 o'clock position and the screen is securely fastened to the unit.

