

# Technical Data Sheet

## Tula Front Steel Panel Installation Instructions

*Assembly 91-8291012*

### **INCLUDED IN KIT:**

- (1) Steel Panel
- (2) "L" shaped mounting brackets
- (2) Mounting screws
- (2) Brass washers

### **TOOLS REQUIRED:**

- 3mm Hex Key
- 5mm Hex Key

- 1) Remove the Stone front Panel from the Tula.
  - a. Using a 3mm hex key remove the set screw that holds the stone in place.
  - b. Pull the stone away from the stove.



Figure 1 – Removing set screw

- 2) Remove the 2 screw/posts from under the stove. These will be reused to mount the steel panel back in place.



Figure 2 – Removing set screw/posts

- 3) Remove the top two outer screws as shown in Figure 3. (these will be reused to hold the mounting brackets in place.)



Figure 3 – Removing set screw/posts

- 4) Place the “L” shaped mounting clips in place and reinstall the screws that were removed.



- 5) Place the steel panel in position and replace the two lower screws that were removed in Step #2. Using the 2 screws provided, thread them through the steel panel into the mounting brackets.

