

Technical Data Sheet

Installation of the Starlet Blower Assembly *Part Number 95-58500*

Date: 1/8/2003

Page: 1 of 1

Tools Required:

None

Zip Bag Contents:

#7200-602 Control Knob (1)

#3900-050 Plastic Feet (2)

#4500-2180 10-24 x 2" Fully Threaded Rods (2)

Procedure:

1. The blower is freestanding under the back of the stove. Position the blower so that it fits between the back of the stove's firebox and the rear heat shield shell. The snap switch must fit up against and make contact with the back of the firebox.
2. Install the two leveling feet by first putting the plastic feet onto one end of each of the threaded rods and then turning the other end of the rods into the back bottom of the blower housing until it sits level on the hearth. **IMPORTANT: DO NOT TURN THE A.DJUSTMENT FEET IN TOO FAR. MAKE SURE THEY DO NOT CONTACT THE RHEOSTAT CONTROL ON THE RIGHT SIDE OF THE BLOWER.**

Blower Operation:

A snap switch located on the top of the blower housing activates the blower. It will take several minutes for the heat of the stove to activate the snap switch. A rheostat controls the blower fan speed. The rheostat knob is located on the right hand side of the blower housing. Turn the knob clockwise to the on position. The fan is on the highest setting when it is first turned on. By continuing to turn the knob clockwise the fan movement will be reduced until it reaches its lowest setting. If the fan does not operate at the lowest setting, the rheostat will require adjustment. Contact your dealer for rheostat adjustment. To turn the blower off, turn the knob fully counterclockwise until it clicks into the off setting.