





Proflame II Remote Quick Reference Sheet

Remote Icons and Structure:



Battery Orientation:





Remote Operation:



ON/OFF Key

This button turns the appliance ON or Off in manual mode.



THERMOSTAT Key

3 Possible Settings:

- 1) ON - Appliance will operate in thermostat mode with ability to manually set the flame height, fan speed, light, & front and rear burners.
- 2) OFF - Thermostat is off, but appliance will operate manually from remote using ON/OFF key.
- 3) SMART - Operates the same as in ON mode but the SMART function will modulate the flame height as the fireplace nears the set temperature.



MODE Key

Pressing the MODE key will cycle the display screen through flame modulation, fan modulation, light ON/OFF, Split Flow ON/OFF, and Aux ON/OFF.



Use the UP/DOWN Arrow Key to adjust each setting accordingly.

Setting the following features requires powering the stove off from the remote (receiver switch on stove in REMOTE position):



Child Lock:

To activate child lock, press the Mode Key and the Up Arrow Key at the same time.
To deactivate press the same button sequence.



Fahrenheit / Celsius Mode Select:

With the system in the OFF position, press the Thermostat Key and the Mode Key at the same time



Continuous Pilot/Intermittent Pilot (CPI/IPI)

Allows the selection of a continuous (standing) pilot or intermittent pilot (only lit when appliance calls for heat). A continuous pilot keeps the firebox warm, thus maintaining a draft which allows for easy starts (recommended when exterior temperatures drop below 50 degrees F.

Press Mode to index CPI icon. Using the arrow key select CPI or IPI mode. A snowflake icon will be visible during setup and will remain visible in CPI mode.

Warning/Safety Features:



Battery Icon

Appears on remote control LCD when batteries (in the remote only) require replacement.

System Lockout

The Proflame II system has a safety mode designed to detect ignition errors. If this system is triggered, the appliance will not turn on either manually or from the remote. Call your service provider to have the unit inspected and reset.