

Technical Data Sheet

Installation of the Sterling "G" Direct-Vent Restrictor Plate *Assembly 95-65010*

Date: 1/2/2003

Page: 1 of 1

KIT CONTENTS:

- 1 – 5950-920: Restrictor Plate
- 1 – 3610-101: 5" x 6-1/2" Gasket Ring

TOOLS REQUIRED:

Phillips Screwdriver

NOTE: This kit is for use with the Dura-Vent 4" x 6-5/8" stove adapters only.

BEFORE YOU BEGIN:

To determine if a Restrictor Plate is necessary refer to the venting charts in the Owner's Manual. If a Restrictor Plate is needed, select and fix it in the proper setting by again referring to the venting chart.

PROCEDURE:

- 1) A 5" X 6-1/2" gasket ring is required on the sides of the Restrictor Plate. Position one gasket and the Restrictor Plate on the inner collar of the stove. Install the Restrictor Plate with the hole divider up at a 1:00 o'clock position and with the adjustment screw facing out towards you.

HINT: Use Spray >n Glue or liquid gasket glue to help hold the gasket rings in place during assembly.

- 2) Position a second 5" X 6-1/2" gasket ring on top of the Restrictor Plate and install the 4" inner collar on top of the gasket rings and Restrictor Plate. Secure the assembly with 8 of the screws provided with the stove adaptor kit.
- 3) Install the 6-5/8" outer stove adaptor and 8" X 9-1/2" gasket ring with the remaining 8 screws.